

PAT(3)
Triple E Branch A



thread	Tube size (mm)(3)						
(PT)	Ø 4	Ø 6	Ø 8	Ø 10	Ø 12	Ø 14	Ø 16
M5							
1/8"	04-01	06-01	08-01				
1/4"	04-02	06-02	08-02	10-02	12-02		
3/8"	04-03	06-03	08-03	10-03	12-03		
1/2"	04-04	06-04	08-04	10-04	12-04		

PHT(1)
Single Universal Tee



thread	Tube size (mm) (1)						
(PT)	Ø 4	Ø 6	Ø 8	Ø 10	Ø 12	Ø 14	Ø 16
M5							
1/8"	04-01	06-01	08-01	10-01			
1/4"	04-02	06-02	08-02	10-02	12-02		
3/8"	04-03	06-03	08-03	10-03	12-03		
1/2"	04-04	06-04	08-04	10-04	12-04		

PHT(2)
Double Universal Tee



thread	Tube size (mm) (2)						
(PT)	Ø 4	Ø 6	Ø 8	Ø 10	Ø 12	Ø 14	Ø 16
M5							
1/8"	04-01	06-01	08-01	10-01			
1/4"	04-02	06-02	08-02	10-02	12-02		
3/8"	04-03	06-03	08-03	10-03	12-03		
1/2"	04-04	06-04	08-04	10-04	12-04		

PHT(3)
Triple Universal Tee



thread	Tube size (mm) (3)						
(PT)	Ø 4	Ø 6	Ø 8	Ø 10	Ø 12	Ø 14	Ø 16
M5							
1/8"	04-01	06-01	08-01	10-01			
1/4"	04-02	06-02	08-02	10-02	12-02		
3/8"	04-03	06-03	08-03	10-03	12-03		
1/2"	04-04	06-04	08-04	10-04	12-04		

PA
Branch A



thread	Tube size (mm) (2)						
(PT)	Ø 4	Ø 6	Ø 8	Ø 10	Ø 12	Ø 14	Ø 16
M5	04-M5						
1/8"		06-01					
1/4"			08-02	10-02			
3/8"				10-03	12-03		
1/2"					12-04		

PAF
Female Branch A



thread	Tube size (mm) (2)						
(PT)	Ø 4	Ø 6	Ø 8	Ø 10	Ø 12	Ø 14	Ø 16
M5	04-M5						
1/8"		06-01					
1/4"			08-02	10-02			
3/8"				10-03	12-03		
1/2"					12-04		

PCP
Coupler Plug



MODEL (tube)
PCP04
PCP06
PCP08
PCP10
PCP12

PKD
Male Reducer
Triple Branch



MODEL (tube1-tube2-thread)
PKD0604-01
PKD0804-01
PKD0804-02
PKD0806-01
PKD0806-02
PKD1006-02
PKD1006-03
PKD1008-02
PKD1008-03

PUL
Union Elbow



MODEL (tube)
PUL04
PUL06
PUL08
PUL10
PUL12
PUL14
PUL16

PY
Union Y



MODEL (tube)
PY04
PY06
PY08
PY10
PY12

PXT
Bulkhead Union Elbow



MODEL (tube-tread)
PXT04-01
PXT04-02
PXT06-01
PXT06-02

PWJ
Plug-In Reducer Y



MODEL (tube1-tube2)
PWJ0604
PWJ0806
PWJ1008
PWJ1210

PMM
Bulkhead Union



MODEL (tube)
PMM04
PMM06
PMM08
PMM10
PMM12

PUC
Union Straight



MODEL (tube)
PUC04
PUC06
PUC08
PUC10
PUC12
PUC14
PUC16

PW
Reducer Y



MODEL (tube1-tube2)
PW0604
PW0804
PW0806
PW1006
PW1008
PW1208
PW1210

PG
Reducer



MODEL (tube1-tube2)
PG0604
PG0804
PG0806
PG1006
PG1008
PG1208
PG1210
PG1612

PYJ Plug-In Y



MODEL (tube)
PJY04
PJY06
PJY08
PJY10
PJY12

PP Plug



MODEL (tube)
PP04
PP06
PP08
PP10
PP12
PP16

PGJ
Plug-In Reducer



MODEL (tube1-tube2)
PGJ0604
PGJ0804
PGJ0806
PGJ1006
PGJ1008
PGJ1206
PGJ1208
PGJ1210

PGT
Reducer Tee



MODEL (tube1-tube2)
PGT0604
PGT0806
PGT1006
PGT1008
PGT1208
PGT1210
PGT1610
PGT1612

PLM
Bulkhead Union Elbow



MODEL (tube)
PLM04
PLM06
PLM08
PLM10
PLM12

PIJ
Tube Splicer



MODEL (tube)
PIJ04
PIJ06
PIJ08
PIJ10
PIJ12
PIJ16

PUT
Union Tee



MODEL (tube)
PUT04
PUT06
PUT08
PUT10
PUT12
PUT14
PUT16

PXJ Plug-In Reducer Double Y



MODEL (tube1-tube2)
PXJ0604
PXJ0806

PZA
Union Cross



MODEL (tube)
PZA04
PZA06
PZA08
PZA10
PZA12

PPF Cap



MODEL (tube)
PPF04
PPF06
PPF08
PPF10
PPF12
PPF16